




# 1283 BECKER SERIES




128320 SOFA




128317L or R ONE ARM SOFA  
\*SHOWN AS RIGHT ARM




128314 ARMLESS SOFA




128318L or R ONE ARM SOFA W/RETURN  
\*SHOWN AS LEFT ARM




128351 CONDO SOFA




128350L or R ONE ARM CONDO SOFA  
\*SHOWN AS RIGHT ARM




128349 ARMLESS CONDO SOFA




128304 CHAIR




128305 CORNER




128313 LOVESEAT




128310L or R ONE ARM LOVESEAT  
\*SHOWN AS RIGHT ARM





128309 ARMLESS LOVESEAT



128307L or R ONE ARM CHAISE  
\*SHOWN AS RIGHT ARM



128301 OTTOMAN



128320 SOFA SHOWN  
\*NOT TO SCALE

Scale:  $\frac{1}{4}'' = 1'-00''$

This schematic is current as 02/15. The company reserves the right to change dimensions and products offered. A more recent schematic may be available for this series. To see the most current schematic, go to <http://lazarind.com>

\*NOTE: L or R IS DETERMINED BY FACING AT THE PIECE